

Powder Forming Using Dynamic Magnetic Compaction

Edward A. Knoth, Bhanu Chelluri




IAP Research, Inc.

www.iap.com

International Conference on High Speed Forming 2010




Railguns - Magnetics at Work



28 Years of Development at IAP



The Big Bang – a Record Test



Test conducted January 31, 2008



Business Thrusts

➤ Railguns

- ❑ Support the Navy and Army thrust to field a system

➤ Power Electronics

- ❑ Technology development for high power density
- ❑ Product development for Navy applications
- ❑ Product development for commercial applications

➤ Advanced Materials and Processes


- ❑ Nano composite materials – magnetics, bearings, medical
- ❑ Advanced FRP for railgun application
- ❑ Rail materials and coatings
- ❑ Armature advanced materials and designs
- ❑ Magnetic pressing of powder materials and metals




Presentation Outline

- **Powder material processing basics**
- **Dynamic Magnetic Compaction (DMC) process**


All Powder Processes Have The Same Steps




All Powder Processes Have The Same Steps



All Powder Processes Have The Same Steps



All Powder Processes Have The Same Steps



All Powder Processes Have The Same Steps

Powder



Load Tooling


Compact

Part Removal


Sinter/Cure

Finish Machining

Ship



How Dynamic Magnetic Compaction (DMC) Works



Ductile and brittle powder materials can be compacted

- Current
- Magnetic Flux
- Magnetic Pressure




DMC Can Made Precise Parts



- AGMA 9 rating
- Conventional process machines forged blanks




Armature Kinetic Energy Compacts The Powder




- Magnetic pressure launches armature
- Powder and core tool stop armature



High Pressures Give High Density





DMC Creates High Density Green Parts



Density Improves Magnetic Properties


Material	Process	Br kG	Hc Oe	$\mu_{max} \times 10^3$
Powder Iron w/Resin	DMC	3.57	4.90	0.44
EMI Resin	Conv.	2.93	5.76	0.30
1008 Steel	Lamination	10.86	3.63	1.44




Doubled
rotational speed
capability



Dynamic Compaction For Ceramics



**Successful tile size
scaled-up through
process development**



a) DMC & PS

b) CONV & PS

- **DMC delivers high density compacts**
- **Fine microstructures**



DMC Pressing Feature Summary

- DMC compactions deliver high density
 - ❑ Kinetic process => High compaction pressure
 - ❑ Metal material properties like wrought
 - ❑ Promotes a fine grain structure
- DMC a natural for radial pressing
 - ❑ High L/D part shapes
 - ❑ Net shaped parts
- DMC can produce flat (non round) part shapes



Questions?

Ed Knoth

(937)296-1806

Ed.Knoth@iap.com

Bhanu Chelluri

(937)296-1806


Bhanu.Chelluri@iap.com




Supplemental Charts




Opposing Currents Generate Magnetic Pressure



Magnetic Pressing Metal Forming and Assembly




Pencil Core Dimensional Requirements Met



Parameter	Average Value	Range	Maximum Value	Minimum Value	PPK
Density(g/cc)	7.57	0.097		7.50	2.08
Length(mm)	77.17	0.460	77.67	76.67	1.76
Diameter (mm)	13.22	0.094	13.32	13.12	2.45

Process Capability



MAGNEPRESS[®] Systems



Power
Supplies

Cables

Coil

Operator
Panel

